

Surface Films Formed on Ni-Cr-Fe Alloys including Alloy 600 and Alloy 690

Feng Wang and T.M. Devine

Department of Materials Science and
Engineering

University of California
Berkeley

Acknowledgements

Electric Power Research Institute, Palo Alto, CA

Dr. Peter Andresen, GE Global Research Center for assistance with design of high pressure/high temperature Ti- water loop.

Dr. Christopher Kumai, UC Berkeley, for design of Ti autoclave and Raman spectrometer.

Overview

SERS

Alloy 600

Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe

Alloy 690

Diffusion Path Analyses

Introduction


Alloy 600

Mild Cr-depletion

Strong Cr-depletion



Alloy 690

Samples in titanium autoclave with sapphire window



Gold particles for SERS on Alloy 600

-500mV



-600mV

Test Procedure

Immerse in aqueous solution at 22°C and **heat at 1°C/min** to 300°C or 320°C. Measure SERS at **50°C intervals** during heat up.

Test Procedure

Immerse in aqueous solution at 22°C and heat at 1°C/min to 300°C or 320°C. Measure SERS at 50°C intervals during heat up.

At 300°C/320°C step potential in increments of 50 mV, hold for 15 minutes and measure SERS (-900 mV to -450 mV vs SHE).

Identify passive film of Alloy 600 and Alloy 690 (Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe)

Test Procedure

Immerse in aqueous solution at 22°C and **heat at 1°C/min** to 300°C or 320°C. **Measure SERS** at 50°C intervals during heat up.

At 300°C/320°C step potential in increments of 50 mV, hold for 15 minutes and measure SERS (-900 mV to -450 mV vs SHE).
Identify passive film of Alloy 600 (Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe)

Cool to 22°C and **measure SERS**.

Test Procedure

Immerse in aqueous solution at 22°C and heat at 1°C/min to 300°C or 320°C. Measure SERS at 50°C intervals during heat up.

At 300°C/320°C step potential in increments of 50 mV, hold for 15 minutes and measure SERS (-900 mV to -450 mV vs SHE).

Identify passive film of Alloy 600 (Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe)

Cool to 22°C and measure SERS.

Remove sample from autoclave, **expose to air** and **measure SERS**.

Alloy 600: heated to 300°C, polarized from -900 mV
to -460 mV vs SHEs


Alloy 600: heated to 300°C, polarized from -900 mV

to -460 mV vs SHEs

1200 ppm B + 0.2 ppm Li
Sat'd with N₂-4%H_{2(g)}

Alloy 600: heated to 300°C, polarized from -900 mV
to -460 mV vs SHEs


1200 ppm B + 0.2 ppm Li
Sat'd with N₂-4%H_{2(g)}



)

Alloy 600: heated to 300°C, polarized from -900 mV to -460 mV vs SHEs

1200 ppm B + 0.2 ppm Li
Sat'd with N₂-4%H_{2(g)}




Identify Passive Film (540, 610, 680 cm^{-1})

Nickel



300°C

540 cm^{-1} = NiO




Ni

540 cm⁻¹ = NiO




Cr - 300°C



Ni-5Cr-8Fe


$540 \text{ cm}^{-1} = \text{Cr}_2\text{O}_3$



Ni-10Cr-8Fe


$540 \text{ cm}^{-1} = \text{Cr}_2\text{O}_3$

$680 \text{ cm}^{-1} = \text{spinel } \text{NiCr}_2\text{O}_4 (?)$




Alloy 690 300°C

540 cm^{-1} and 610 cm^{-1} = Cr_2O_3



Alloy 690 300°C


540 cm⁻¹ and 610 cm⁻¹ = Cr₂O₃




Summary

Alloy 600's passive film at 300° and 320°C= $\text{Cr}_2\text{O}_3 + \text{NiCr}_2\text{O}_4$

Comparison to Other Researchers: Alloy 600 PWRpw 360°C/300h




Comparison to Other Researchers:



J. Panter et al., JNuclMaterials 348 (2006) 213-221

Comparison to Other Researchers:



A. Machet ^{a,b}, A. Galtayries ^{a,1}, S. Zanna ^a, L. Klein ^a, V. Maurice ^a, P. Jolivet ^b,
M. Foucault ^c, P. Combrade^c, P. Scott ^b, P. Marcus ^{a,*}
Electrochimica Acta 49 (2004) 3957–3964

Comparison to Other Researchers: High Temperature Water

Alloy 600 High purity water 392°C = NiFe_2O_4
543°C = NiFe_2O_4 , CrOOH and Cr_2O_3 (RS)

J.e.Maslar et al., JECS, 156 C103 (2009).

Alloy 600 in H_2 sat'd water (pH=10) at 285°C
10 nm Cr_2O_3

N.S. McIntyre, JECS 750 (1979)

Alloy 600 350°C 30cc/Kg H_2 $\text{Cr}_2\text{O}_3/\text{CrOOH}/\text{NiCr}_2\text{O}_4/\text{NiO}$
1 cc/Kg H_2 $\text{Cr}_2\text{O}_3/\text{CrOOH}/\text{NiO}$

Ji Hyun Kim and Il Soon Hwang, 11th Internat Conf on Envir Degrad

Alloy 625 (22Cr 8Mo 4Fe) and Alloy 718 (18Cr 3Mo 18Fe)
In SCW at 600°C: $(\text{Cr,Fe})_2\text{O}_3/\text{spinel}/\text{NiO}$
X.Ren et al., Corrosion, 63, 603 (2007)

Comparison to Results of Other Researchers: Gaseous Oxidation

Ni-10Cr air oxidation **inner layer of Cr₂O₃** (continuous at T>900°C)

Outer layer of NiO

D.L. Douglas, Corros. Sci., 8, 665 (1968).

Ni-16Cr-9Fe and Ni-17Cr-7Fe

0.4-4min thin (1nm) **inner layer of Cr₂O₃** and outer layer of Cr(OH)₃ + Ni(OH)₂
4.8 min Cr₂O₃ increases and CrOOH decreases.

Cr₂O₃ on Ni-20Cr in flowing 10⁻⁴Pa of O₂ at 550°C

J.F. Schmitt et al. Oxidation of Metals, 44, 429 (1995).

Comparison to Other Researchers: Aqueous 25°C

Alloy 600 passivated at -200 mV and 0 mV/2h vs SCE in 0.5M NaCl (**RT**)

AES => **2 nm thick inner layer of Cr₂O₃**, a middle layer of iron oxide and an outer layer of NiO

Cr depletion in the alloy beneath the passive film

G. Lorang,¹ N. Jallerat,¹ K. Vu Quang¹ and J.-P. Langeron,
SURFACE AND INTERFACE ANALYSIS, VOL. 16, 325-330 (1990)¹

Ni21Cr8Fe, Ni17Cr10Fe in 0.05M H₂SO₄ at **RT**

Inner layer of 96%Cr₂O₃+4%Fe₂O₃ (6.5Å)

Outer layer of Cr(OH)₃ (4.5Å) ESCA

P.Marcus and J.M. Grimhal CorroSci, 33, 805 (1992)

Summary

Alloy 600's passive film at 300° and 320°C = $\text{Cr}_2\text{O}_3 + \text{NiCr}_2\text{O}_4$

Ni-5Cr-8Fe and Ni-10Cr-8Fe passive film = $\text{Cr}_2\text{O}_3 + \text{NiCr}_2\text{O}_4$

Alloy 690's passive film = Cr_2O_3

Alloy 690's film is fundamentally different than the films formed on Alloy 600, Ni-5Cr-8Fe and Ni-10Cr-8Fe.

Overview

SERS

Alloy 600

Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe

Alloy 690

Diffusion Path Analyses

Introduction

Alloy 600


Mild Cr-depletion

Strong Cr-depletion

Alloy 690


Diffusion Path Analyses - Rhines

Diffusion Couple




Diffusion Path Analyses - Rhines (~1940)

Diffusion Couple





J.S.Kirkaldy
D.E. Coates



Diffusion Path Analyses

J.S.Kirkaldy
D.E. Coates


Diffusion Couple



Diffusion Path Analyses of Oxide Film Growth

Assumptions: Transport through the film is RDS
=> interfacial reactions are in equilibrium


Diffusion Couple



Diffusion Path Analyses of Oxide Film Growth

Assumptions: Transport through the film is RDS
=> interfacial reactions are in equilibrium

Diffusion Couple




Thus, the complete microstructure of the surface is predicted from knowledge of (1) the ternary Ni-Cr-O phase diagram, and (2) the diffusivities of Ni, Cr, and O in each of the phases present in the phase diagram.

Diffusion Path Analyses of Oxide Film Growth

Assumptions: Transport through the film is RDS
=> interfacial reactions are in equilibrium

Diffusion Couple



For Alloys 600 and 690 in water at 320°C, we don't know the phase diagram or the diffusivities. However, important information about the film is obtained by measuring the species present in the film and plotting the results on an assumed phase diagram.

Overview

SERS

Alloy 600

Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe

Alloy 690

Diffusion Path Analyses

Introduction

Alloy 600

Mild Cr-depletion

Strong Cr-depletion

Alloy 690

Hypothesized Ni-Cr-Water Ternary Phase Diagram* at 300°C




Figure 1. Hypothetical ternary Ni-Cr-Water phase diagram at 300°C.

NB - diagram is significantly distorted

* Based on Ni-Cr-O at 1000°C, Croll and Wallwork

Ni-Cr-Water Ternary Phase Diagram





Figure 1. Hypothetical ternary Ni-Cr-Water phase diagram
at 300°C.

Ni-Cr-Water Ternary Phase Diagram



SERS of
Alloy 600

Figure 1. Hypothetical ternary Ni-Cr-Water phase diagram at 300°C.

Overview

SERS

Alloy 600

Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe

Alloy 690

Diffusion Path Analyses

Introduction

Alloy 600

Mild Cr-depletion

Strong Cr-depletion

Alloy 690

Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path





Figure 1. Hypothetical ternary Ni-Cr-Water phase diagram
at 300°C.

“Mild” Cr-depletion
of Alloy 600
contacting oxide


Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path




Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path



Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path



Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path

Outermost layer
of NiO

Middle layer of
Spinel

Inner layer of
 Cr_2O_3

“Mild” Cr-depletion
of Alloy 600
beneath oxide




Figure 1. Hypothetical ternary Ni-Cr-Water phase diagram
at 300°C.

Overview

SERS

Alloy 600

Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe

Alloy 690

Diffusion Path Analyses

Introduction

Alloy 600

Mild Cr-depletion


Strong Cr-depletion

Alloy 690

Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path for “Severe” Cr-depletion of Alloy 600

“Severe”
Cr-depletion
Of Alloy 600
Beneath oxide



Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path for “Severe” Cr-depletion of Alloy 600

“Severe”
Cr-depletion
Of Alloy 600
Beneath oxide





Figure 1. Hypothetical ternary Ni-Cr-Water phase diagram at 300°C.

Evidence of spinel as the inner layer of Alloy 600’s film: Ziemniak and Hanson, (Corr. Sci., 48, p498 (2006)): inner layer of NiCr₂O₄ and outer layer of NiFe₂O₄.
=> Diffusion path exits the NiCr₂O₄ phase and crosses the two phase NiCr₂O₄+ NiFe₂O₄

Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path for “Severe” Cr-depletion of Alloy 600



Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path for “Severe” Cr-depletion of Alloy 600




Figure 1. Hypothetical ternary Ni-Cr-Water phase diagram at 300°C.

Evidence of spinel as the inner layer of Alloy 600’s film: Ziemniak and Hanson, (Corr. Sci., 48, p498 (2006)): inner layer of NiCr_2O_4 and outer layer of NiFe_2O_4 .
 => Diffusion path exits the NiCr_2O_4 phase and crosses the two phase $\text{NiCr}_2\text{O}_4 + \text{NiFe}_2\text{O}_4$

Ni-Cr-Water Ternary Phase Diagram

Construction of Diffusion Path for “Severe” Cr-depletion of Ni-16Cr

Outer layer of NiO
 Inner layer of Spinel
 “Severe” Cr-depletion of Alloy 600 beneath oxide





Figure 1. Hypothetical ternary Ni-Cr-Water phase diagram at 300°C.

Results suggest that conditions that cause **severe Cr depletion** of Ni-16Cr (\approx Alloy 600?) will produce an **inner layer of spinel** and an **outer layer of NiO**


Ni-Cr-Water Ternary Phase Diagram

Diffusion Paths of Alloy 600, Ni-10Cr-8Fe, Ni-5Cr-8Fe




Ni-Cr-Water Ternary Phase Diagram

Diffusion Paths of Alloy 600, Ni-10Cr-8Fe, Ni-5Cr-8Fe



Similar films of Alloy 600, Ni-10Cr-8Fe, and Ni-5Cr-8Fe indicate low value of $[Cr]_{\gamma}$ in equilibrium with spinel: i.e., $[Cr]_{\gamma} < 5\%$;
 $[Cr]_{\gamma} \approx 10\%$ at 1000°C (Croll and Wallwork, 1969)

Before comparing the films of Alloy 600 and Alloy 690, we reiterate the Alloy 600's Oxidative Diffusion Path



Diffusion path during oxidation of Alloy 600

Figure 39. Two diffusion paths (DP) of Alloy 600 sketched on a hypothetical ternary Ni-Cr-Water phase diagram at 300°C. The DP are based on SERS measurements. Note that the ternary phase diagram is distorted. For example, the sizes of the single phase regions of NiO and Cr₂O₃ are relatively large, and the oxygen concentrations of NiO, spinel, and Cr₂O₃ are indicated as being equal. The two-colored Red + Blue path represents DP#1 in which the film formed on Alloy 600 consists of an inner layer of Cr₂O₃ and an outer layer of NiCr₂O₄. The single colored Red path represents DP#2 in which Alloy 600's film consists of an inner layer of Cr₂O₃, and intermediate layer of NiCr₂O₄, and an outer layer of NiO. The dashed lines are the portions of the DP that pass

Point of Detail of Alloy 600's Oxide Diffusion Path




Figure 40. Two diffusion paths (DP) of Alloy 600 through the Cr₂O₃ region. The red colored path through the Cr₂O₃ phase field indicates the ratio of cation transport to anion transport is extremely small. The nearly horizontal portion of the blue colored path indicates the ratio of cation transport to anion transport is very high.

Overview

SERS

Alloy 600

Ni, Cr, Ni-5Cr-8Fe, Ni-10Cr-8Fe

Alloy 690

Diffusion Path Analyses

Introduction

Alloy 600

Mild Cr-depletion

Strong Cr-depletion

Alloy 690

Construction of Diffusion Paths of Alloy 690 at 300°C and 320°C





Figure 41. Two diffusion paths (DP) of Alloy 690. The DP at 300°C is colored red. The DP at 320°C is colored blue.

At 300°C, DPA => Alloy 690's film is a consequence of (1) the alloy's high [Cr], and (2) the growth of Cr₂O₃ is controlled by O⁼ diffusion.


Construction of Diffusion Paths of Alloy 690 at 300°C and 320°C



More severe Cr depletion of Alloy 690 at 320°C results in mixed cation M₂O₃

Figure 41. Two diffusion paths (DP) of Alloy 690. The DP at 300°C is colored red. The DP at 320°C is colored blue.

Comparison of Diffusion Paths of Alloy 690 and Alloy 600



Approximately
no [O⁼] gradient
in Cr₂O₃ of
Alloy 600

Figure 41. Two diffusion paths (DP) of Alloy 690. The DP at 300°C is colored red. The DP at 320°C is colored blue.

At 300°C, DPA => Alloy 690's film is a consequence of (1) the alloy's high [Cr], and (2) the growth of Cr₂O₃ is controlled by O⁼ diffusion.

Summary

Ni-5Cr-8Fe, Ni-10Cr-8Fe, Alloy 600 have films of Cr_2O_3

+ Spinel (NiCr_2O_4 ?)

Alloy 690's Film = Cr_2O_3

Diffusion Path Analyses

Value of Empirical Diffusion Path Analyses

In general, DPA helps explain the observed films' microstructures

In the particular case of Alloys 600 and 690, DPA indicates fundamental differences in the films of Alloy 600 and Alloy 690

e.g. Cr_2O_3 (A690) vs Cr_2O_3 + spinel (A600)

Cation gradient in Cr_2O_3 of A600 vs Oxygen ion gradient in Cr_2O_3 of A690.

Future Work

High resolution compositional analyses throughout the thickness of the films of Alloy 600 and Alloy 690

TEAM at NCEM, LBNL

Transmission Electron Aberration-Corrected Microscopy

Map results onto the ternary Ni-Cr-Water phase diagram and the quarternary Ni-Cr-Fe-Water phase diagram